REMEMBER THIS IMPORTANT TIP

Control the water current in your container with the AIR CONTROL VALVE.

The more air added with your valve, the slower your water current will be.

Adjust water flow with the AIR CONTROL VALVE, until the fish are schooling and in a stationary position in the tank.

Adjusting the water current for the species of your fish will keep them in prime condition.

If water flow is too fast, fish will tire quickly.

REMEMBER.....
ALWAYS KEEP YOUR FILTERS CLEAN!