INSTRUCTIONS FOR ALL
KEEPALIVE PUMPS AND ACCESSORIES

Operation of the KeepAlive Air Inlet Valve: When your unit is provided with a 1/8" air check valve, install it in line next to the Air Control Center with a small portion of the air hose provided.

It is recommended that all threaded fittings must have no less than pipe thread tape sealant.

ALWAYS DOUBLE CHECK FOR LEAKS!