



Gene Turner Hook Plucker

To use the Hook Plucker if a fish is hooked in the lip or the side of the mouth where the hook can be seen, Catch the hook with the side of the Hook Plucker and pull the fishing line tight....With the line held tight and straight in line with the Hook Plucker, givh the fish a quick, brisk flip over the Hook Plucker and the fish should come right off the hook.



If a fish is hooked down inside the mouth or throat, straddle the hook with the end slot on the Hook Plucker.....Hold the line and the Hook Plucker tight, push and twist on the hook and it should come loose.



If you need a quick fish billy, turn the Hook Plucker around and hit the target with the handle end of the Hook Plucker.