THRU-HULL MODELS

To install the thru-hull models we recommend you follow the livewell diagram and instructions on pages 11 and 13 as a general guide. There are too many different hull and livewell designs for only one type of installation. KeepAlive components were designed for the angler to create a custom livewell.

Tips

- Always use a ball valve at the thru-hull pickup.
- Always use strainer KA102 to prevent pump from clogging.
- Clean strainer frequently.
- Be sure drain size is large enough to accommodate pump.